



USE OEM HARNESS - UNMODIFIED

**DO NOT CONNECT MAP
CONNECTOR TO ANYTHING
MAP SENSOR IS CONNECTED
TO PINS 1,3,7 AND IS UNUSED
FOR THIS APPLICATION**

WIRE GAUGES

**PINS 1-3-9: 20 AWG
PINS 2-4-5-7-8-10: 22 AWG**

BENG - BABICH ENGINEERING
CREATED BY: HUNTER BABICH
EMAIL: hunterbabich@babichengineering.com
DATE: 05/25/2025

**This wire diagram is released as open source
under the MIT License. It is unrestricted for use,
modification, and distribution, with no warranty
provided. For details, see the MIT License terms.**