

RHBC-MH	C1			Right HB controls to Main Harness		
CONNECTOR	DTM04-4P					
BOOT	SCL					
NOTES						
Location	Pin/Seal (Part Number)	Wire Size (AWG)	Color	Destinations (End 1, End 2)	Line	Line Description
1	0460-010-20141	18	BLACK	P1-C1 / RS Switch	L1	+12V Run/Stop Input
2	0460-010-20141	18	BLACK / WHITE	P2-C1 / RS Switch	L2	+12V Run/Stop Output
3	0413-204-2005	PLUG			PLUG	
4	0413-204-2005	PLUG			PLUG	
RHBC-ECU	C2			Right HB controls to ECU Harness		
CONNECTOR	DTM04-2P					
BOOT	SCL					
NOTES						
Location	Pin/Seal (Part Number)	Wire Size (AWG)	Color	Destinations (End 1, End 2)	Line	Line Description
1	0460-010-20141	18	YELLOW / RED	P1-C2 / Start Btn	L5	Sensor Ground
2	0460-010-20141	18	BLACK / RED	P2-C2 / Start Btn	L6	ECU Input for Start Button
FBRK	C3			Attaches to Front Brake Switch		
CONNECTOR	DTM04-2P					
BOOT	SCL					
NOTES						
Location	Pin/Seal (Part Number)	Wire Size (AWG)	Color	Destinations (End 1, End 2)	Line	Line Description
1	0460-202-20141	20	BLUE	P1-C3 / FBRK	L7	Ducati Brake Switch - Wire Lead
2	0460-202-20141	20	BROWN	P2-C3 / FBRK	L8	Ducati Brake Switch - Wire Lead